

PA800 Series Parking Adaptor and Stand

Help Keep Loading Arms Safe and Secure

The OPW Parking Adaptor and Stand helps ensure loading arms are correctly stowed and secured when not in use. Some can also be used to collect drips and pipe them away to the drain system.

The bottom-loading API coupler can be coupled with an integral proximity sensor (supplied separately) and is actuated to enable system interlocks. All adaptors have stops to ensure couplers cannot be opened while in the parked position.

Features and Benefits:

- All parking adaptors have stops to help ensure coupler cannot be opened while parked
- Some parking adaptors can be used to collect drips and pipe them away to a drain system
- Parking adaptors can be supplied with a proximity switch to enable system interlocks

Materials of Construction:

- Nose Cone - Aluminum
- Spring - Stainless Steel
- Slider - Acetal
- Stand - Painted Carbon Steel



Ordering Information:

Item Number	Description
PA801	API Parking Adaptor
PA811	API Parking Adaptor w/Proximity Switch Holder
PAS801-ES	API Parking Adaptor with Stand
PAS811-ES	API Parking Adaptor (w/ Proximity Switch Holder) with Mounting Stand
5544	Proximity Switch for Parking Adaptor

